

# Vidyo Gateway Dialing Procedures

For Outside NICNET (for Public IPs)	For NICNET only (for Private IPs)
<b>Vidyo to H.323 VC System</b>	<b>Vidyo to H.323 VC System</b>
41x.x.x.x (SD)	31x.x.x.x (SD)
41x.x.x.x,conf ID (SD)	31x.x.x.x,conf ID (SD)
<b>H.323 VC System to Vidyo Endpoint</b>	<b>H.323 VC System to Vidyo Endpoint</b>
164.100.176.235##41xxxxxx (SD Point to Point)	10.120.64.135##31xxxxxx (SD Point to Point)
164.100.176.235##42xxxxxx (SD V-Room)	10.120.64.135##32xxxxxx (SD V-Room)
<b>From CISCO Endpoint to Vidyo Endpoint</b>	<b>From CISCO Endpoint to Vidyo Endpoint</b>
41xxxxxx@164.100.176.235 (SD Point to Point)	41xxxxxx@10.120.64.135 (SD Point to Point)
42xxxxxx@164.100.176.235 (SD V-Room)	42xxxxxx@10.120.64.135 (SD V-Room)
<b>Cisco MCU to Vidyo - SD/HD</b>	<b>Cisco MCU to Vidyo - SD/HD</b>
164.100.176.235!41xxxxxx(P2P)-SD	10.120.64.135!31xxxxxx(P2P) -SD
164.100.176.235!42xxxxxx(Conf. Room) -SD	10.120.64.135!32xxxxxx(Conf. Room) -SD
<b>Polycom RMX to Vidyo</b>	<b>Polycom RMX to Vidyo</b>
164.100.176.235 Extension/ID String P1*ID# ( V. Room)	10.120.64.135 Extension/ID String P1*ID# ( V. Room)
164.100.176.235 Extension/ID string P2*ID# (P2P)-SD	10.120.64.135 Extension/ID string P2*ID# (P2P)-SD
x.x.x.x- IP Address Of H.323 System	H.323 VC System - Polycom, Life Size
xxxxxx - Extension Of Vidyo User ID	